

B12S20L ASSEMBLY INSTRUCTIONS

- STEP 1: PLACE FRONT BARREL ASSEMBLY AND HANDLE ASSEMBLY ONTO A FLAT SURFACE.
- STEP 2: PLACE LOCK WASHER ONTO ROD ON HANDLE ASSEMBLY.
- STEP 3: PULL ROD OUT OF THE BARREL UNTIL FLATS ON ROD ARE ACCESSIBLE. USING A 7/16" WRENCH, ASSEMBLY RODS TOGETHER WHILE HOLDING PULL, IF NECESSARY USE AN ADJUSTABLE WRENCH ON PULL NUT. NOTE, WASHER SHOULD SIT IN BETWEEN RODS WHILE ASSEMBLING.
- STEP 4: ATTACH COUPLING TO HANDLE ASSEMBLY.

