



ATTENTION!

If control switch cannot be activated with normal hand/finger pressure, hold backcap steady and rotate carriage/barrel to reduce pressure.

If rod is stuck and will not disengage automatically, press and quickly release the trigger. Then, press the control switch and slowly pull back on the rod.

