



12v Piston/Rod/Barrel Assembly Instructions

- Step 1. Remove contents from box.
Step 2. Insert rod and piston assembly through front of handle.




- Step 3. Assemble pull with screw.




- Step 4. Pull rack until piston assembly is about 1" from back cap.

- Step 5. Assemble barrel. Lubricate piston if needed.




12v Piston Assembly Instructions

- Step 1. Screw stud onto rack until it completely seats onto the rack.



- Step 2. Screw tube nut onto stud until it seats onto the rack. Tighten the tube nut securely.



- Step 3. Install piston assembly

